

## Spartan® SMS Command Code List

Add Phone	*100#number#	Phone number added
Delete Phone	*101#number#	Phone number deleted
Add Email	*110#email#	Email added
Delete Email	*111#email#	Email deleted
Send Via MMS	*120#0#	Send via MMS
Send Via Internet	*120#1#	Send via Internet (When send via is Internet, "Send To" will be modified to Email only)
Send To Phone	*130#0#	Send to phone
Send To Email	*130#1#	Send to email
Send To Both	*130#2#	Send to both (When send via is Internet, "Send To" will be modified to Email only)
Camera Mode Photo	*200#0#	Set to photo mode
Camera Mode Video	*200#1#	Set to video mode
Send Mode Instant	*140#0#	Send instant photo
Send Mode Daily Report	*140#1#	Send daily report
Send Mode Off	*140#2#	Send is off

## Spartan® SMS Command Code List

Signal Level	*150#	The signal is very weak/weak/good/very good
Power Level	*201#	Battery Level 1 to 5 (low to high)
Set PIR Level to High	*202#0#	PIR sensitivity high
Set PIR Level to Normal	*202#1#	PIR sensitivity normal
Set PIR Level to Low	*202#2#	PIR sensitivity low
Set PIR Level to Off	*202#3#	PIR sensitivity off
Turn SMS Off	*104#	Camera Turned Off
Take Photo and Send Now	*500#	Picture sending ("Invalid" when the camera mode is Video.)

### SMS Control Function

The Spartan® wireless camera can be controlled by sending SMS command to the camera phone number.

### SMS Switch

In order to use the SMS control function, the user need to set the switch to ON in the setup process.

### The Commander Phone Number

The Recipients Phone number you set in the setup process will be the commander phone number.